

To set time and day

- 1 Press **SET CLOCK/DAY/SCHEDULE***
 - 2 Press **▲/▼** to set time
 - 3 Press **SET DAY**
 - 4 Press **▲/▼** to select day
 - 5 Press **Done** to save & exit
- *If this option is not displayed, press **DONE, RUN SCHEDULE** or **CANCEL**

To set program schedule

- 1 Press **SYSTEM** to select Heat or Cool
- 2 Press **SET CLOCK/DAY/SCHEDULE***
- 3 Press **SET SCHEDULE**
- 4 Press **▲/▼** to set the Wake time, then press **NEXT**
- 5 Press **▲/▼** to set the Wake temperature, then press **NEXT**
- 6 Repeat steps 4-5 to set Leave/Return/Sleep time periods
- 7 Repeat steps 4-6 to set time periods for other days
- 8 Press **DONE** to save & exit

To override program schedule

- Press **▲/▼** to change temp for this time period only
- Press **HOLD, ▲/▼** to change temp for all time periods
- Press **RUN SCHEDULE** or **CANCEL** to resume program

Copyright © 2020
Resideo Technologies, Inc.
All rights reserved.
M.S. Rev. 10-20



69-1778ES-06

Para ajustar el día y la hora

- 1 Oprima **SET CLOCK/DAY/SCHEDULE***
 - 2 Oprima **▲/▼** para ajustar la hora
 - 3 Oprima **SET DAY**
 - 4 Oprima **▲/▼** para ajustar el día
 - 5 Oprima **Done** para salir
- *Si esta opción no aparece, oprima **DONE, RUN SCHEDULE** o **CANCEL**

Para fijar el programa de horarios

- 1 Oprima **SYSTEM** para seleccionar Heat o Cool
- 2 Oprima **SET CLOCK/DAY/SCHEDULE***
- 3 Oprima **SET SCHEDULE**
- 4 Oprima **▲/▼** para ajustar la hora de Wake, y oprima **NEXT**
- 5 Oprima **▲/▼** para ajustar la temperatura de Wake, y oprima **NEXT**
- 6 Repita los pasos 4-5 para fijar los períodos Leave/Return/Sleep
- 7 Repita los pasos 4-6 para fijar los períodos para otros días
- 8 Oprima **DONE** para salir

Para anular el programa de horarios

- Oprima **▲/▼** para cambiar temp. para este período
- Oprima **HOLD, ▲/▼** para cambiar temp. para todos los períodos
- Oprima **RUN SCHEDULE** o **CANCEL** para seguir con el horario