


T87F Easy-to-See Thermostat Homeowner's Guide

Features of Your New Thermostat

1. Enlarged, raised numbers indicate temperature range for easy recognition by touch or sight. The large 5, 6, 7 and 8 mean 50°F, 60°F, 70°F and 80°F, respectively.
2. Raised temperature setting knob lets you choose settings from 42°F to 88°F.
3. Temperature setting scale is separate from thermometer scale on face of thermostat.
4. Thermometer shows room temperature.



M6106



Temperature Selection

To select the temperature, turn the transparent dial until the desired point on the setting scale (upper scale) is aligned with the pointer on the dial. A *click* is heard and an indent felt every two degrees as the setpoint is adjusted. A deeper indent is felt at the 10 degree mark for easy energy saving setting at night.

The enlarged cover ring includes raised temperature graduations every two degrees Fahrenheit. The enlarged raised 5, 6, 7 and 8 provide recognition by touch and sight for the 50°F, 60°F, 70°F and 80°F points.

NOTE: If the information on this card is desired in Braille, call 1-800-468-1502, Monday-Friday, 7:00 AM - 5:30 PM, Central time for a copy.

Honeywell

Home and Building Control

Honeywell Inc.
Honeywell Plaza
P.O. Box 524
Minneapolis, MN 55408-0524

Home and Building Control

Honeywell Limited-Honeywell Limitée
155 Gordon Baker Road
North York, Ontario
M2H 3N7

